




USB to UART



Power




earphone



UART JMP



PWRKEY



SIM868


SIM868



BT ANT




GSM ANT



GPS ANT

Antenna




PPS

STA


NET

UART LED

Indicator light



SIM_CAR



Raspberry Interface



GSM/GPRS/GNSS HAT